

MLC-S Sprinkler Pipe & Fittings for Concrete Ceilings

Universal Casting Cup for Sprinklers in Concrete Floors

Removal Tool




Sizes

27mm Wrench

Tech Data Sheet

Contact Tyco for details

The Removal Wrench is used for removing the Installation Cup. The tool can be used in combination with a 1/2" Socket Drive or a 27mm Wrench.



MLC-S Removal Tool

Part No.	Dimension	H	Ø	Qty
560004301	27mm (1/2") Socket	44	55	1